

ISSUE

The front light must be moved when installing the Bread Basket on the Spicy Curry, and Mundo V5.

SOLUTION

There is extra slack in the front light wiring in the frame of the Spicy Curry, and in the fork of Mundo V5 to be pulled for light relocation to front of bread basket.

INSTALLATION

Step 1:

Remove light from fork crown by removing the fender bolt. Reinstall fender and steering stabilizer.

Step 2:

Gently pull around 16-20 inches of front light wiring from fork crown (Mundo V5) , or downtube (Spicy Curry).

Step 3:

Secure light wiring to basket tubing using cable ties.

Step 4:

Remount light on front of bread basket using M5 x 30mm bolt, washers, and nylock nut.

STEP 2

*Spicy Curry:
Pull Wire From Downtube*



*Mundo V5:
Pull Wire From Fork Crown*



STEP 3

Secure Wiring to Basket Tubing



STEP 4

Remount Light on Bread Basket

