

Spicy Curry Chainstay Protector Install



Tools needed:

- Rag
- Isopropyl alcohol or similar cleaning solution

Steps:

Step 1: Remove existing protector if present



Step 2: Clean chainstay thoroughly. Remove any sticky residue left behind from the original protector and any dirt/chain grease



Step 3: Before removing adhesive backing cover, mock up the chainstay protector on the chainstay. It should be about two fingers width from the chainstay/seatstay bridge



Step 4: When you have the position set, remove the adhesive backing cover and firmly press protector to chainstay

